

Foam Tipped Applicator

Wood shaft



- USP Grade Cotton under foam Tip

- White Birch Shaft

Actual Size

Description

This absorbent foam tipped applicator is produced with reticulated 100ppi Medical Grade foam over High Quality USP grade cotton which is carded and coiled onsite to maintain consistency. It is bonded securely to a rigid white birch shaft.

Dimensions

6" Overall Length (152.4mm)

Tip

- .937" Length (23.8mm)
- .375" Width (9.53mm)

Shaft

- 5.812" Length (147.62mm)
- .100" Dia. (2.54mm)

Qualities

- Lint and residue free
- Cotton under foam provides extra absorbancy
- Soft smooth tip
- Can be used with IPA and DI water, or dry
- Shaft made from a renewable resource

Standards

- ISO 9001:2008
- FDA GMP's

Applications

Critical Environment & Industrial

- Applying adhesives or other solutions
- Removing dirt, contamination, fluxes or resins
- General cleaning

Ref #	Packaging
1806-WCF	20/50 (20 resealable poly bags per case, 50 swabs per bag)
1806-WCFB	4/250 bulk (4 poly bags per case, 250 swabs per bag)



Quality Medical Products Since 1919

Puritan Medical Products Company LLC
Guilford, Maine 04443-0149 USA

Tel 800-321-2313 (US and Canada Only)
207-876-3311

Fax 800-323-4153
207-876-3130

Web www.puritanmedproducts.com

Email sales@puritanmedproducts.com

1-800-321-2313
puritanmedproducts.com

Foam Tipped Applicator

Wood Shaft

1806-WCF / 1806-WCFB

NVR

NON-VOLATILE RESIDUE

Test method IDEMA method M7-98

NVR Solvent - Hexane

NVR 50 µg/swab

The minimum detection limit for NVR is 10 µg/swab

ION CHROMATOGRAPHY TESTING RESULTS

IONIC CLEANLINESS

Test method IDEMA M13-99 (anions) M12-99 (cations)

ANIONS

Fluoride	ND	µg/swab
Chloride	2.3000	µg/swab
Nitrate	ND	µg/swab
Bromide	1.9800	µg/swab
Nitrate	0.8800	µg/swab
Sulfate	4.3000	µg/swab
Phosphate	4.3800	µg/swab

CATIONS

Lithium	ND	µg/swab
Sodium	7.5240	µg/swab
Ammonium	0.3480	µg/swab
Potassium	12.6240	µg/swab
Magnesium	1.4880	µg/swab
Calcium	2.8200	µg/swab

ND - Non Detected

Test procedures available upon request.



Quality Medical Products Since 1919

Puritan Medical Products Company LLC
Guilford, Maine 04443-0149 USATel 800-321-2313 (US and Canada Only)
207-876-3311Fax 800-323-4153
207-876-3130Web www.puritanmedproducts.comEmail sales@puritanmedproducts.com1-800-321-2313
puritanmedproducts.com